

RELAVIT


GLASSWASH

Auto glasswash detergent


A machine glasswash detergent that removes stains and soiling, leaving glassware sparkling. RELAVIT GLASSWASH is pre-softened for effectiveness in both hard and soft water.

Use to clean glassware, glasses and tumblers in all automatic glass washing machines. Suitable for use in pubs, clubs, nightclubs, restaurants and bars.

METHOD OF USE



1 Wear correct PPE when changing dishwashing tubes.




2 Turn off the dishwasher and remove the existing detergent.



3 Carefully remove the dishwashing tube out of the RELAVIT Glass wash container.



4 Place the tube into the new container of RELAVIT Glasswash.



5 Put the RELAVIT Glasswash back by the dishwashing machine.



6 Run the dishwasher cycle to ensure the product is pulling through.

DOSAGE

WATER HARDNESS	
SOFT WATER	1 - 2mls per litre of water
HARD WATER	2 - 4mls per litre of water

PRODUCT INFO



Pack Size:	5L
Product Code:	328
Odour:	Characteristic
Colour:	Yellow
pH (undiluted):	13.5
Shelf life:	2 years



For Health & Safety information, please scan the QR code provided.

THINK SAFE, CLEAN GREEN

Christeyns Professional Hygiene UK Ltd | Clover House | Whaley Bridge
SK23 7DQ | T +44 (0) 1663 733 114 | W www.christeyns-ph.co.uk


CHRISTEYNS
PROFESSIONAL HYGIENE



WARE
WASHING

RELAVIT

GLASSWASH

AUTO GLASSWASH DETERGENT



- TAINT-FREE AND NON-FOAMING FORMULA
- ECONOMICAL IN USE
- ANTI-CORROSIVE – PROTECTS YOUR MACHINE

PRODUCT DESCRIPTION

A machine glasswash detergent that removes stains and soiling, leaving glassware sparkling. RELAVIT Glasswash is pre-softened for effectiveness in both hard and soft water.

Use to clean glassware, glasses and tumblers in all automatic glass washing machines. Suitable for use in pubs, clubs, nightclubs, restaurants and bars.

INSTRUCTIONS FOR USE

Put dosing tube into the container of RELAVIT Glasswash, so that it reaches the bottom. The dosing unit, which has been pre-set to a specific concentration, will automatically dispense RELAVIT Glasswash into the machine.

For best results, use in conjunction with Christeyns' RELAVIT Rinse T. Ensure that the thermostat on the machine is set correctly.

RELAVIT Glasswash can be added manually for each cycle if required. Typically 1-4ml per litre of water should be added to the machine for each wash cycle depending on the water hardness.

ADDITIONAL INFORMATION

Product code: 328
pH Level: 13.5

STORAGE

Store between 5 and 40°C

PACKAGING

2 x 5 Litre

NON WARRANTY

This information is based on our current knowledge and is intended to describe the product for the purposes of health, safety and environmental requirements only. It should not therefore be construed as guaranteeing any specific property of the product.

